


Electrical Switch Options

Please identify which switch system you have.

Rocker Switch - 240v. single phase.



Part No: BO1285

Seperate Stop and Start Push Button



Stop Push Button - Part No: KS0017

Start Push Button - Part No: *BO1172 & * BO1180

*Both parts are required

MACHINE SPARES LTD.

Garratt St. Brierley Hill, West Midlands, DY5 1JU.

Tel: 0870 870 2550 Fax: 0870 870 2660